WITS Level 0 Passive Connector

WITS servers outputting Level 0 data streams

- Name: **WITS0Passive**
- Version 1.0.12.0
- Protocol: WITS Level 0 Passive
- Interface: TCP/IP, UDP or RS232
- Runtime: .NET 2.0 (Multiplatform)
- Configuration:
    - Devices / Protocols

Module Configuration
Channels Configuration
Nodes Configuration
Points Configuration
Driver Revision History

Overview

WITS0Passive communication driver implements communication with server running WITS Level 0 communication. This driver runs only in listening information from the server.

> **NOTE**
>
> This driver supports any tag defined on target system.

Module Configuration

This document has only information about the device connection settings and its address syntax.

For further Information, see:

- Devices Module
- Devices Module Reference

Channels Configuration

Settings

- **AcceptUnsolited Messages**: Must be checked to enable this driver
- **Listening Port**: Listening port the TCP or UDP messages

Nodes Configuration

Address

The address is necessary, as this driver works in listening mode only. When connecting to multiple devices, multiple channels shall be defined.

Points Configuration

The syntax for the communication point is: ***RecordID:ItemID***

Where:

- ***RecordID*** and ***ItemID*** ranges from **01** to **99**, according to the WITS Level 0 record definition.

Driver Revision History

WITS0Passive Revision History	
Version	**Notes**
1.0.12.0	Initial release on new documentation standards.

In this section...