# **Redundancy and Service Configuration**

## FactoryStudio Redundancy Overview

FactoryStudio has built-in features to deploy redundant systems; both at the server level as well at the data acquisition level, allowing the deployment of fault-tolerant systems in an easy and reliable process.

Project synchronization is a concern when using redundancy, but FactoryStudio has tools to simplify it by bringing an effective collaborative engineering in place.

### Server Redundancy Types

There are two basic types of server redundancy approaches, "Hot-Hot" and "Hot-Standby".

In most cases, the "Hot-Standby" is the preferred way to implement fault-tolerant systems.

#### **Hot-Hot Redundancy**

For a Hot-hot scenario, two servers and all of the servers' modules are running at all times. A custom application (typically, the TRemoteClient driver) does the synchronization of the Operator Inputs between the servers. When the application is feeding remote SQL databases or exchanging data with third party systems, a custom code on the application must ensure the data is not doubly written.

The Hot-Hot configuration is used when the process does not allow any switching time from the primary to the secondary. Therefore, there is no concept of "active server". Both servers are fully active at all times. The remote client's Displays can access the project from either server. In order to create Hot-Hot scenarios with FactoryStudio, you need to have two servers running. You need to use the TRemoteClient to synchronize any necessary data between the servers, and use the Script to enable or disable pieces of the running application as required by the duplicated operation.

The disadvantage of the Hot-Hot implementations is that they require custom project engineering. Especially when you have integration with other applications and when the data-acquisition from the field devices is duplicated, which causes an extra load on the network of devices and potentially causes a difference of time-stamps among each station.

How to manage two operators in each station trying to give commands at same time as well as the integration of remote SQL and file system in order to avoid data duplication must be decided at the application level.

For these reasons, the Hot-Standby configuration is the preferred option when implementing fault-tolerant servers. The Hot-Hot scenario is mainly applied when the server activation time of the hot-standby, usually from 1 second to a few seconds, is not acceptable for the process. Otherwise, the Hot-Standby has as simpler configuration, no custom engineering, and it automatically guarantees data consistency among the servers.

#### Hot-Standby Redundancy

In this scenario, there are two servers that have the project loaded, but only one server (the ACTIVE one) is running all the modules. The STANDBY server has the modules in a PAUSED state and is receiving the data synchronization from the ACTIVE computer to update its local memory but is not executing the tasks.

The redundancy is automatically implemented by FactoryStudio, using a simple configuration dialog. There is no need for custom programming, custom applications. Any project created as a standalone project can be deployed as a fault-tolerant pair with no engineering required, even when connected to third party systems.

The communication between the servers uses a WCF TCP/IP communication, which can be encrypted and uses any WCF feature. The data exchange uses a Tatsoft algorithm developed by years of field-experience, which synchronizes the data using a publisher-subscriber model that sends data only by exception (events and data-changes) in an efficient and reliable way.

Most importantly, the redundancy is not an external module. It is "redundancy-to-the-core". FactoryStudio was designed from principals to have built-in, at the kernel level, support for fault-tolerant applications.

When the STANDBY server detects the ACTIVE computer is down, it changes the Modules from the Pause state to the Run state; starting with the realtime database's states and values according to how it had been received from the synchronization.

The detection of the Active Server is done typically by using a watch-dog message on the same TCP/IP channel that is being used to exchange the synchronization data, but the custom switch determinations can be added if needed. The "Connection Timeout" parameters in the redundancy configuration is the inactive time of the Active computer that makes the standby computer go live; the typical value for that number is from one second to ten seconds, depending on the network and servers.

## FactoryStudio Redundancy Configuration

The Hot-Standby redundancy is configured in the Info-Project-Redundancy dialog.

The configuration is under the INFO tab (not the EDIT tab) because there are no changes to the project itself. Configuring redundancy is just about starting the exact same project with the optional redundancy parameters.

	🂽 🧐 🕾   🕹 📲 🎼   🚭 🛧   🗟 🔍 Tag.Controle_Sil 🔐   🤣 🚿 🐂			
🌞 🚘 💽 🚺	Version Settings Redundancy			
Edit Draw Run Info	Command Line settings			
	Primary Server IP: 192.168.0.1 Target Port: 3101			
	Secondary Server IP: 192.158.0.2 Target Port: 3101			
Project	On Primary Startup: Switch to primary, put secondary in stand-by If secondary is active, put primary in stand-by			
	Historian Replication: None ConnectionTimeout: 5 s Copy to clipboard			
Track	Server Command Line:     Tstartup.exe /project:"C:\Users\Marcos\Downloads\LRC_Serra_Morena\LRC\LRC.tproj" /     redundancy /ip1:192.168.0.1 /ip2:192.168.0.2 /connectiontimeout:5			
	Rich Client command: TRichClient.exe /ip1:192.168.0.1/ip2:192.168.0.2/connectiontimeout:5			
Notes	Smart Client url: http://192.168.0.1/fs-2014.2/TSmartClient.application?			
	Web Client url: http://192.168.0.1/fs-2014.2/TWebClient.xbap			
FactoryStudio	View-Only Windows Authentication			
Help				
🔹 License				

### Server Redundancy Configuration

The key parameters to configure are:

**ConnectionTimeout**: Watch-dog time in seconds. This is the time the standby computer uses to monitor the activity of the active computer between doing the automatic switch. The Switch between active and standby can also be by command. In this case, the switch is immediate. Only the time to change the modules from Pause to Run on the standby computer is needed. The time ranges typically from one second to five seconds but is very dependent on specific project configuration, the server computers, and the network.

ConnectionRetry: Number of connection retries, default is one.

Primary and Secondary IP/Computer names: The computer IP address or DNS names of the computers that will work together as a fault-tolerant pair. They will run the exact same project configuration, and either one can be ACTIVE or STANDBY at any given time. The only differences between the one designed as the Primary and the one designed as the Secondary are:

- Primary precedence: If you start two servers at the same time and a conflict arises the computer will have the role of ACTIVE. If both are on, the role will go to the Primary computer.
- On Primary Startup: When the Secondary is the ACTIVE server and the Primary computer is down, the Primary computer starts. You can specify if the Secondary will stay as the ACTIVE server, or if the Primary server will take over the ACTIVE state after it finishes its initialization, which will automatically change the Secondary computer to the STANDBY role. The configuration is using the "On Primary Startup" option.

Based on these settings, a custom command line for the TStartup.exe is created and presented on the configuration line. When you are deploying redundant configuration, you need to use the command line on Windows AutoStart or on the Windows Service configuration if you are running FactoryStudio as a Windows Service.

### Data redundancy configuration

When running fault-tolerant applications, the Alarm Archiving server and the Historian archiving server can be located on the same computer as the FactoryStudio servers or on a third computer dedicated to the archiving, such as a Microsoft SQL Server or Oracle server. The "Historian Replication" configuration provides support to the many scenarios.

When the Historian is on a remote database machine, there is no need to do Replication on FactoryStudio. Since only one computer is ACTIVE, either the Primary or Secondary will write to the external database. In this case, you define "no replication" for the configuration.

Note that the external database can still be a fault-tolerant cluster that uses the Database redundancy tools, but the cluster is viewed by the FactoryStudio project as just one external connection.

If you are running either the Alarm database or the Tag historian database on the same computer as the FactoryStudio servers, you need to enable the respective Replication option.

### Server parameters

When using redundancy, there is a set of parameters that can be assigned to both TStartup.exe and TServer.exe to specify its behavior. The command line is automatically created on **Info-Project-Redundancy**, but you can customize the command lines directly as needed. These are the parameters used:

- /ip1: <Primary Server Name or IP>
- /ip2: <Secondary Server Name or IP>
- /Port1: <Port number of primary, default is 3101>
- /Port2: <port number for secondary, default is 3101>
- /project: <full path of the project file>
- /connectionTimeout: <watch-dog timeout in seconds, accepts decimal points>
- /username: <startup user>
- /redundancy (has no parameters, just need to be included to enable redundancy)
- /autoswitch (has no parameters. if included, the Primary takes over as the Active node if the secondary was acting as Active)
- /TimeAutoSwitch: <number of seconds the Primary waits before becoming active if the autoswitch option is enabled. Typically set to 60 seconds.</li>
   /ProjectIPPath: <IP>:<Path of the project on the remote servers.</li>
- /ProjectIPPath: <IP>;<Path of the project on the remote server>
- The ProjectIPPath is used by the system to allow one station to automatically update the project in the redundant pair when doing online project changes and HotStart commands. Example:
- /ProjectIPPath:192.168.0.1;C:\FactoryStudio\Projects\test.tproj

The TimeAutoSwitch time is connected when you are using the */autoswitch* option. In this scenario, when the computer designed as the Primary starts, it will "auto switch" from standby to active after it starts. It is important that the switch happens only after the process had time to get all the synchronization from the active computer. Typically, 60 seconds should be enough for that, but you should increase that settings for large projects or slow networks.

## **Collaborative Engineering**

FactoryStudio's centralized project configuration makes it easy to keep a project synchronized on both servers. All the project settings are only in one of two files, the tproj or trun file. You just need to make sure the file is the same on both computers when deploying your project.

Note that the switch depends on many factors: if there are pending operations, the project size, the computers, and the network. The total switch time is typically measured in seconds, but it is necessary to conduct a test on your specific scenario to specify the right parameters for the connection timeout and retry parameters.

You can setup your own procedure to synchronize the two files, or use FactoryStudio's automated methods for hot-standby configuration.

### **Online changes**

Option 1: Local IPC acting as the Primary Server

• MS Command Line for TFS Eng App and Runtime Debugging Tool:

"C:\Program Files (x86)\Tatsoft\FactoryStudio\fs-2014.2\TManagerExe.exe" /project:"C:\FactoryStudio\Projects\ExampleProject1.tproj"

tools

"C:\Program Files (x86)\Tatsoft\FactoryStudio\fs-2016.2\PropertyWatch.exe" /ip1:computer name /username: Administrator

- When you open the FactoryStudio Engineering application, use the configuration tools, and connect to a Server running a project with the Online configuration checkbox enabled, the Server can be on the same computer with the configuration tools or on a remote computer.
- In this case, every change you make to the project is applied immediately to the running application.
- The runtime property @ Server.UpdateProjectOnInactiveServer will propagate online changes on the active server to the backup server.

Option 2: For online changes, you should use the TPROJ file, instead of TRUN, and do the following steps:

- Connect the Engineering tools on the STANDBY computer.
- Do the modifications online, or press the HotStart button to apply the previously made changes.
- In the application (in an administrator display), execute the command Server.SwitchToStandby(), so the computer with the new project will be active.
- Finally, execute a trigger on property Server.UpdateProjectOnInactiveServer that will apply the changes to the other computer.
- If you want to return the Active state to the original computer, just run the Server SwitchToStandby() method again

### **Offline changes**

The command line parameter /ProjectIPPath option allows you to define a verification path. When the application starts, it verifies the project configuration against the reference provided on the remote computer.

For off-line changes:

- Make your project changes on another computer, and create the TPROJ or TRUN file to be installed for production use.
- Stop the runtime in the Standby computer, copy the TPROJ file, and start the runtime again.
- Switch the Active to the server that is updated, and stop the runtime in the other system.
- Either use the \ProjectIPPath parameter to enable the Standby computer to get the configuration from the server automatically when starting, or copy the file to the second computer
- Start the runtime

### **Hot Start**

You can make changes to a project when it is running even if you are not connected to it. When you make changes to a project and apply all the new changes at once without stopping the application, it is called "hot-swapping". To do this: After you make your project changes, connect to the server, and press the HotStart button in the Run-Startup dialog.

🌞 💺 🕟 🕕	Startup
eait Draw Run inio	Startup Settings UserName: Admin - Password:
-	Project server: localhost Port: 3101 PortWA: 3102 Use Only Windows Authentication
Build	Startup computer:   Local Execution Path:   Project Server   Custom:   Custom:   Custom:   Custom:   Custom:   Custom:
Test	Run Local Diagnostics Tools     Run Modules       Image: Construction in the second sec
Startup	Property Watch     Datasets     A Historian     Displays     Scripts     OPCServer
Publish	Hot Start Run Startup
Tools	Enable online configuration

## **Runtime changes**

It is possible to update projects without using engineering tools. There is a method @Server.LoadProjectVersion(<project>), which allows dynamic loading of new project configuration. This command can be included with the application itself or inside an external .NET application connected to the server.

## Client configuration based on Redundancy scenario

FactoryStudio clients are easy to configure on any redundancy scenario. There is no programming or advanced configuration required. You just need to start the client station with the right parameter, as showed on **Info-Project-Redundancy**, examples: TRichClient.exe /ip1:192.168.1.1 /ip2:192.168.1.2 /connectiontimeout:5

#### http://192.168.1.1/fs-2014.1/TSmartClient.application?connectiontimeout=5;ip2=192.168.1.2

Clients do not even need to install any project files on their machines. Client computers will get all the project information from the server. The RichClient only needs FactoryStudio on the client computer. When using the SmartClient, the only thing needed is Internet Explorer installed on the client computer.

This is how it works: When the client starts (either the RichClient or SmartClient) it looks for the ip1 computer to connect. If it is not found, it switches to the ip2 computer. If the client loses connection with the server computer, it will try automatically to switch to the redundant pair without stopping the operator operations.

## **Redundancy Interaction over Client**

Clients can visualize critical redundancy information and even make a server switch using FactoryStudio runtime properties and methods.

#### Switching the active server

There is a method included in FactoryStudio: @Server.SwitchToStandby()

That method will force the Active server to handle control of the Standby server; if the standby server is not running, the command fails, and the execution is kept on the same computer. If you want to use this feature, you need to create a protected display or button in an application screen.

#### Visualizing redundancy status

The following are the most used properties:

- @Server.IsPrimary // True, if the active server is the Primary
- @Server.IsSecondary //True, if the active server is the Secondary
- @Server.IsStandByActive //True, if the standby computer is up and running
- @Server.IsSwitchToPrimaryEnabled //True, when configuration is to the Primary is always Active
- @Server.RedundancyPendingObjects //Number of objects pending synchronization
- @Server.UpdateProjectOnInactiveServer //Allow Online changes/HotStart to replicate to the standby computer
- @Server.SwitchToStandby() // Request to the active server to switch to standby

## Running the Application as Windows Service

When running the application as a Windows Services, you need to take 4 actions:

- Setup the Run-time startup: By using the FactoryStudio configuration tools or directly editing the Windows Service system, you define a FactoryStudio project to start as a Windows Service that will run the "server" components of the project. The graphical user interface always runs in a Windows User Mode in the same computer or started in a remote computer.
- Setup a Web Server: If you want remote access to this project (for project configuration or to access the displays in runtime), you need to setup a Web Server. This is accomplished with the built-in TWebServer software or with the Microsoft IIS (Internet Information Services).
- Verify the security settings: Verify the security settings of the Windows Service and the security settings of the FactoryStudio project.
  Define the client startup: When a FactoryStudio project is starting as a Windows Service, the Displays will not run, despite the project configuration, due to the restrictions of it running as a service. Therefore, you need to setup the client displays, either in a startup shortcut on the same computer or in a remote computer.

## Configuring FactoryStudio to Runtime AutoStart as a Service

ictoryStudio		presented by TATSOF
Projects	Server	License
Connected Server: localhost runnning version fs-2014.2 Runtime autostart:		
Project Server:		
Remote: http://127.0.0.1:3100/     Victural notion		
Cloud: http://www.EngineeringOnTheCloud.com		
Account: MS1/Marcos Connect Password: Forgot your password?		

FactoryStudio can be set to start as a service which reduces downtime. This can be done on its Welcome window. On Server tab, click on the Settings... button.

In "Select runtime auto startup mode", choose the Service option to run the project as a service when the computer starts, and select which project you want. Finally, click the Apply Settings button.

	Projects	Server
Ņ	Setup a project to automatic startup on server localhost Current settings:	
	Select the runtime auto startup mode:	
	O None: projects are started only with a command, local or remote.	
	O Login: run project when an user login and stop on user logout	
	Service: run project as a service when computer starts, independently of user logins	
	OPC Activation: runtime is activated by remote OPC client connections	
	Project: C:\FactoryStudio\Projects\Project79_v1.0.trun	
	Apply settings	<< Back

#### 1. Setup TWebserver as Service

If the project uses SmartClients for visualization, it is recommended to configure the TWebServer to run as a service as well.

You should uninstall the current TWebServer with the command prompt (e.g.: C:\Program Files (x86)\Tatsoft\FactoryStudio) and executing:

InstallTWebServer /uninstall /port:80

For running the TWebServer as a service, you can execute the InstallTWebServer using the parameter /windowsservice.

And for choosing a specific port, you can use the parameter /port:<portnumber>.

InstallTWebServer /windowsservice /port:1234

In order to setup Microsoft IIS, see the project documentation.

### 2. Verify the Security Settings

#### Verify the Windows Security settings for Log On

When you setup the project to run as a Windows Service, it will run by default under the built-in "Local System" Window Credentials. For some projects, especially if accessing external databases or folders, you may need to run under a specific user's Windows Security Log On credentials. The configuration is executed in the Windows Service Configuration directly. For most scenarios, the default configuration will suffice.

🍓 Services		- 🗆 X				
File Action View Help			Group ^			
Services (Local)	Local)		LocalService			
FactoryStudi	Startup Service Name Description Status	Startup Type Log ^	LocalServiceA			
Start the servi	FactoryStudioStartup Service FactoryStud  FactoryStudioStartup Service Properties (Local Computer) X nning General Log On Recovery Dependencies Log on as:     O necovery Dependencies     Dependencies	Automatic (D Loc Manual Net Automatic Loc Manual Loc Manual Crig Loc Manual Loc Manual Loc Manual (Trig Loc	LocalSystemN LocalService			
rewer details 🧠 Open serv	OK Cancel Apply		1			

#### Optionally, you can delay the start of the service

If the application is using external resources, services, or applications, you may want to delay the start of the project to allow the other services to start first. This is also executed in the Windows Service configuration.

FactoryStudioStart	up Service	Properties (Loc	al Comput:	er)	×
General Log On	Recovery	Dependencies			
Service name:	FactoryStu	dioStartup			
Display name:	FactoryStu	dioStartup Servio	ce		
Description:	FactoryStudioStartup Service			~ ~ ~	
Path to executable: "C:\Program Files (x86)\Tatsoft\FactoryStudio\fs-2016.2\TStartupAsService					
Startup type:	Automatic (Delayed Start) Automatic (Delayed Start) Automatic Magual				
Service status:	Disabled Stopped				-
Start	Stop	Pa	ause	Resume	
You can specify the start parameters that apply when you start the service from here.					
Start parameters:					
		ОК	Cancel	Apply	ſ

#### Setup the Security in FactoryStudio Project

When the application is running as a service, the server components will run under the credentials of the "project user" defined in **Run-Startup**. By default, the user is a "guest". For most projects, that user will be changed to Administrator, which will allow the user to make changes to the project with online configuration or have access to all application objects.

	Startup			
	Startup Settings			
	UserName:	Administrator		Password:
	Project server:	localhost		
	Port:	3101	PortWA:	3102 E Use Only Windows Authentication
	Startup computer:	Local	Execution Path:	• Project Path
Į		Project Server		Custom:

#### 3. Define the client startup

The last step is to set up the start-up or the client displays. The procedure we will describe is the same if the client displays are running in the same computer or in a remote computer.

In order for the client to start automatically, you need to create a shortcut that the operator will click, or you can put the shortcut in the Windows Startup Folder.

The Shortcut will be for the RichClient or SmartClient. The RichClient start faster but need to have FactoryStudio installed on the client computer. The SmartClient do not need any FactoryStudio installation on the client computer, but it needs to have a web server running on the server computer.

The shortcuts can be created using the editing tool in Info-Project-Redundancy

Version Set	Redundancy		
Command Line settings			
Primary Server IP:	127.0.0.1	Target Port: 3101	
Secondary Server IP:		Target Port: 3101	
On Primary Startup:	<ul> <li>Switch to primary, put secondary in</li> <li>If secondary is active, put primary in</li> </ul>	stand-by I stand-by	
Historian Replication:	None	ConnectionTimeout: 5 s	Copy to clipboard
Server Command Line:	tStartup.exe /project:"C:\FactoryStudic	v\Projects\Project9.tproj"	
Rich Client command:	TRichClient.exe /ip1:127.0.0.1		Сору
Smart Client url:	http://127.0.0.1/fs-2016.2/TSmartClier	nt.application	Сору
Web Client url:	http://127.0.0.1/fs-2016.2/html5/index	x.html	Сору
	🧧 View-Only 🛛 🧧 Windows Authenti	cation	

The parameter /IP1 is the address of the server computer. The value 127.0.0.1, the local computer, it is the default value for that parameter. You may have to define other parameters, such as /port1, if you are not using port 3101, or Ip2 and Port2 if you're on a standby scenario.

In order to access a project's displays in a remote server computer, the parameter /ip1 must have the server IP address or the remote computer name. Even though the parameter is called "ip1", it accepts the computer name in the network as long your network has a DNS service enabled.

In order to create the Windows shortcut, you can follow the steps on:

http://tatsoft.com/help/fs-2014/reverb/#page/FactoryStudio/DeployingTheRuntimeApplication.16.13.html#ww505477

When you see the placeholder <IP\_address> in command lines or URLs, it can always be replaced by the Computer Name in a network as long as the DNS services are enabled.

## Starting the Module Monitor interfaces

When you start the application in the user mode, you have the TStartup.exe application, which shows a dialog page with all the modules running, and you can start and stop the modules individually using that interface. The application is not visible when the project server (the TServer application) is started as a Windows Server.

If you want to access the same interface when running as a service, you need to start the PropertyWatch.exe located in the FactoryStudio installation folder (typically c:\Program Files (x86)\Tatsoft\FactoryStudio\fs-2014.2\PropertyWatch.exe).

When running as a service, you need to define the parameters /ip1 and /port1 with the computer name or with the computer IP. The default configuration will not allow a connection in this case. You can define the other optional parameters, such as /username. Ex.: "C:\Program Files (x86) \Tatsoft\FactoryStudio\fs-2016.2\PropertyWatch.exe" /ip1:W10-VS /username: Administrator

Another way to start these tools is to open the project configuration, Run Startup, and hit the connect button. This will enable a button on that dialog that will open the monitoring Tools.