

# ASCII – Generic ASCII Master Protocol

The ASCII driver implements communication with any device using the ASCII protocol on TCP/IP or serial networks. The communications blocks are dynamically created according to the pooling cycle defined on the AccessType for each Device Point.

## Summary Information

**Communication Driver Name:** ASCII

**Implementation DLL:** T.ProtocolDriver.ASCII.dll

**Protocol:** Generic ASCII

**Interface:** TCP/IP and Serial

**PLC types supported:** Any PLC compatible with the ASCII protocol

---

## Channel Configuration

### Protocol Options

**BlockSize:** Defines the maximum amount of characters. The default value is 250

**StartChar:** Defines the start character of incoming messages

**EndChar:** Defines the end character of incoming messages

### Settings

Serial and Multi-Serial channels:

Default configuration:

- **BaudRate:** 9600
- **DataBits:** 8
- **StopBits:** 1
- **Parity:** None

TCP/IP channels:

**NodeConnections:** Defines the maximum number of parallel requests that will be sent to each node (asynchronous communication)

---

## Node Configuration

### Station Configuration

Serial channels: Nothing

TCP/IP channels:

- Station syntax: <IP address>;<Port number>
- Where:

**<IP address>** = The IP address of the slave device in the ASCII network

**<Port number>** = The TCP port where the slave device is listening (default is 502)

Ex: 192.168.1.101 ; 502

---

## Point Configuration

The syntax for the ASCII communication points is: <SequenceId>:<SizeOf>

Where:

- **<SequenceId>** indicates the order of the data where the TX message will be created
- **<SizeOf>** indicates the amount of characters from the configured tag

---

## Access Point

Read and Write commands will generate the same TX message

Incoming messages from the device will be treated as an Unsolicited Message

---

## Example

Point 1

TagName: TagA (value equal ABCD)

Address: 0:3

Point 2

TagName: TagB (value equal 1234)

Address: 2:3

Point 3

TagName: TagC (value equal abcd)

Address: 1:4

The TX message created is: ABCabcd123

---

## Troubleshoot

The status of the driver's execution can be observed through the diagnostic tools, which are:

- Trace window
- Property Watch
- Module Information

The above tools indicate if the operations have succeeded or have failed. A status of 0 (zero) means communication is successful. Negative values indicate internal driver errors, and positive values indicate protocol error codes.