Desoutter – CVIC II Devices

Summary Information

Communication Driver Name: Desoutter

Implementation DLL: T.ProtocolDriver.Desoutter.dll

Protocol: Proprietary Interface: RS232 or RS485

PLC Types Supported: Devices compatible with CVIC II.equipments

Manufacturer: Desoutter

PC Hardware requirements: Serial Port

Channel Configuration

Protocol Options

None

Node Configuration

Station Configuration

None

Point Configuration

Address

The syntax for the Cincinnati communication point is: <Command>

Where:

- **<Command>** = Indicates that this specific command is associated with the specific Tag Name

Command	Description
Time	Time of Test
Date	Date of Test
Torque	Torque of Test
Result	Result of Test

Troubleshoot

The status of the driver's execution can be observed through the diagnostic tools, which are:

- Trace window
- Property Watch
- Module Information

The above tools indicate if the operations have succeeded or have failed. A status of 0 (zero) means communication is successful. Negative values indicate internal driver errors, and positive values indicate protocol error codes.